Welcome

About your phone

Thank you for purchasing the X085 Micromax mobile device. Your X085 mobile device has the following range of attractive features :

- Dual SIM Support
- Digital Camera
- Multimedia
- Blacklist
- Theft Tracker
- Memory Card Support
- Video Recording
- Bluetooth/ WAP and much more

Disclaimers

- Please read all safety precautions and this manual carefully before using your device to ensure safe and proper use.
- The functions explained or listed in this manual may differ from the actual functions appearing in the mobile phone or its user interface. In such a case, the latter shall govern.
- The descriptions in this manual are based on the default settings of your device. Micromax reserves the right to modify the content in this user guide without any prior notice.
- The colors and specifications shown/mentioned in the user guide may differ from the actual product. Images shown are for representation purpose only. Other product logos and company names mentioned herein may be trademarks or trade names of their respective owners.
- Applications and their functions may vary by country, region, software or hardware specifications. Micromax is not liable for performance issues caused by third-party applications.
- Available features and additional services may vary by device, software, or service provider.

Phone Layout

Keys and Parts

1. Receiver	2.Screen	3.Navigation Key
4.OK Key	5.Menu Left	6.Call Key2
7.Call Key1	8.Menu Right	9.Music Key
10.End Key	11.Number(0-9)Key	12."*" Key
13."#" Key	14.Camera	15. LED
16. Torch Key		

SIM/Memory Card Insertion



SIM Card Insertion

1. Open the back cover and remove the battery.
2. Insert the SIM cards in the slots, as shown in the figure on the left.

Memory Card Insertion

1. Open the back cover and remove the battery.
2. Open the memory card slot and insert the memory card in the slot as shown in the figure.
3. Place back the battery and back cover once done.



Brief Intro to the Phone

Basic Operations

1. Switch on

Insert SIM card, install battery, restore the battery cover, and press the End key for a few seconds to turn on your phone.

2. Switch off

Press the End key for a few seconds to turn off your phone.

3. Dial a call

Enter a complete phone number and then press the call key1/call key2 to dial the number
Alternatively, you can make the calls from call logs or messaging.

4. Call volume

While engaged in a call, press the **Up** or **Down** navigation keys to adjust the call volume.

5 Answer incoming call

Press the Call key to answer an incoming call .

6. Latest calls

This mobile phone can store a minimum of 30 calls in the log. In standby mode, press the Call key to view the latest calls.

7. Options during call

While engaged in a call you can:

a. Go to **Options** and select **Hold** to put current call on hold. You can resume your call by going again to Menu and pressing **Unhold**.

b. Go to **Options** and select **Mute** to mute your voice so that the phone's microphone will not transmit sound to the other end. You can resume transmitting your voice again by going to **Options** and selecting **Cancel Mute**.

c. Go to **Options** and select **Add New Call** to make call to a new number..

d. Press the **Up** and **Down** navigation keys to adjust the call volume.

8. Conference Call

a. While engaged in a call, go to **Options** and select **Add New Call** and dial a number. The first call will be put on hold.

b. When the second participant accepts the call go to **Option >Merge Calls** to start a call conference.

You may need to activate Conference call facility on your SIM to avail this feature.

User Guide

X085

Frequently Asked Questions

1.How do I lock/unlock the phone?

a)To lock: Press Left key and then * key lock or unlock the phone.

b)To set phone lock: Go to **Menu> Settings> Security** and then enable **Phone locked**.

2. How do I activate Silent mode?
Go to **Menu> Settings> User Profiles** and choose **Silent** mode.

3. How can I set WAP/GPRS to access the Internet?
To set WAP/GPRS for Internet access:
a. Go to **Menu> Settings> Network Settings>** and enable **GPRS Service.**
b. Select **Menu> Settings> Network Settings>** Data Accounts and select from the list of data accounts listed by the network **provider's SIM.**

4. Is there a facility to blacklist specific numbers?
Yes, you can blacklist a list of numbers so that you do not receive calls from them.
a. Go to **Settings> Security> Blacklist**.
b. Select **Blacklist List** and add the desired numbers to be blacklisted.
Note: You can block messages or calls based on your requirements.

5. Is there a security code to lock/unlock the phone?
Yes. The default security code to unlock the phone is 0000. To change the security code:
a. Go to **Settings> Security> Modify the cellphone password**
b. Input the default code (0000) and then the new code to change the security code.

6. Is there a facility to track my mobile phone?
You can track your phone in case of loss or theft by activating the Mobile tracker mode and configuring an alternate number for receiving messages from the unauthorized user's SIM. .
a. From the main menu, go to **Menu> Settings> Security> Theft Tracker**.
b. Input the password.
c. Enable Theft Tracker status and enter the number for receiving the messages from the lost mobile's SIM card.

7. Can I secure Privacy for messages, Contacts and call logs?

a. Go to **Menu> Settings> Security> Privacy Protection**

b. Enter the default password **0000** to set the privacy protection.

c. Select the desired objects to protect and save the choice. Each time you access the protected feature such as messages, contacts and call logs etc, you will be asked for the password.

Note: You can also change the default password to a password of your choice. The new password will be required to access the protected objects (messages/phonebook/call logs).

8. Can I lock my SIM from Unauthorized Use?
The mobile phone allows you to lock your SIM(s) from unauthorized use.
1.Go to **Settings > Security> PIN.**
2.Set the PIN status to **ON.**

9. How can I use Fixed Dial Dial feature?
Fixed dial numbers lets you restrict the outgoing calls to only certain numbers.
To do this:
1. Go to **Settings> Security> Fixed Dial number**
2. Enter the desired fixed dial numbers.

10. How can I use the torch?
Press the Torch key (refer to layout diagram) to turn on/off the torch.

Useful Keys and Shortcuts

Keys	Effect
# key	Long press to activate silent mode; in editing mode, short press to switch input method.
* key	Press along with left key to lock/unlock the keypad. Short press to choose symbols; quick press repeatedly in dial screen to input +, p, w.
Left key	Short press to enter Menu in standby mode. Performs functions in the lower left display.
Right key	Enter phonebook in standby mode, acts as right function key in all interfaces.
End Key	Hang up a call; reject an incoming call; go back to standby screen; long press to switch on/off the phone.

Safety Guidelines

Safe Driving

- Do not use the phone while driving. When you have to use the phone, please use the personal hands-free kit.
- Do not put it on passenger seat or any place from which it may fall down in case of vehicular collision or emergency braking.

During Flight

- Flight is influenced by interference caused by the phone. It is illegal to use a phone on the airplane. Please turn off your phone during a flight.

In Hospitals

- Consult a physician or the manufacturer of the medical device to determine if they are adequately shielded from RF energy. Switch off your device when regulations posted instruct you to do so.
- To avoid potential interference with implanted medical devices such as a pacemaker, cardioverter, defibrillator, always keep your phone at least 15.3 centimeters (6 inches) from the medical device
- Do not carry the wireless device in a breast pocket.

Unsafe Areas

- Please turn off your phone when you are close to a gas station or in the vicinity of any place where fuel and chemical preparations, or any other dangerous goods are stored.

Taking Care of Your Device

- Keep the device dry. If your device gets wet, remove the battery without turning on the device, wipe it with a dry cloth and take it the service center.
- Do not store the device in high or cold temperature. High temperatures can shorten the life of electronic devices and damage batteries.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not attempt to open the device other than as instructed in this guide. Repairing the phone by yourself other than our authorized service agents/centers goes against the warranty rules.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not store your device near magnetic fields or allow your device to come in contact with magnetic fields for extended period of time.

Battery Recommendation

- Please put the battery in a well-ventilated place out of direct sunlight. Charge the battery at room temperature range.
- If the time span of the battery after charging becomes much shorter than usual, the battery life is at an end. Replace the battery with a new battery of the same make and specification.

- The Battery socket should be located near the device while charging.
- Use manufacturer approved batteries, chargers, accessories and supplies to avoid risk of explosion. Micromax will not be responsible for user's safety when using unapproved batteries or accessories
- The WEEE logo (shown at the left) appears on the product (battery, handset, and charger) to indicate that this product must not be disposed off or dumped with your other household wastes. You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling of such hazardous waste. Collection and proper recovery of your electronic waste equipments at the time of disposal will allow us to help preserve the environment. Recycling of the electronic waste equipment will ensure safety of human health and environment. For more information on best practices for disposal of electronic and electrical waste, please visit to our web site: www.micromaxinfo.com/weee.php.

Copyrights

All rights reserved. Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of Micromax is strictly prohibited.

www.micromaxinfo.com